

VerifEye® Advanced Multi-Circuit Meter

Cat. Nos. 72D48, 73C48, and 73D48



VerifEye®

WARNINGS:

- **RISK OF DEATH OR ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH. DO NOT ENERGIZE METER WITH THE VOLTAGE COVER REMOVED. CAREFULLY READ AND FOLLOW INSTRUCTIONS.**
- **TO AVOID FIRE, SHOCK, OR DEATH**, turn off all power sources supplying the equipment before working on or inside the equipment. Use a properly rated voltage sensing device to confirm that power is off.
- This equipment **MUST** be installed and serviced by an electrician or other qualified personnel, with the requisite knowledge, training, and experience related to the installation and operation of this equipment, and in accordance with applicable codes.
- Do not depend on this product for voltage indication.
- Only install this product on insulated conductors.
- **DO NOT EXCEED 346V Line-to-Neutral or 600V Line-to-Line.** This meter is equipped to monitor loads of up to 346V Line-Neutral. Exceeding this voltage will cause damage to the meter and danger to the user. Always use a Potential Transformer (PT) for voltages in excess of 346V Line-to-Neutral or 600V Line-to-Line. The VerifEye® is a 600 Volt Over Voltage Category III device.
- For use in a Pollution Degree 2 or better environment only. A Pollution Degree 2 environment must control conductive pollution and the possibility of condensation or high humidity. Consider the enclosure, the correct use of ventilation, thermal properties of the equipment, and the relationship with the environment. Installation Category: CAT II or CAT III.

WARNINGS:

- Provide a disconnecting device to disconnect the meter from the supply source. Place this device in close proximity to the equipment, within easy reach of the operator, and mark it as the disconnecting device. The disconnecting device shall meet the relevant requirements of IEC 60947-1 and IEC 60947-3, and shall be suitable for the application. In the US and Canada, disconnecting fuse holders can be used. Provide over-current protection and a disconnecting device for supply conductors, with approved current-limiting devices suitable for protecting the wiring. If the equipment is used in a manner not specified by the manufacturer, the protection provided by the device may be impaired.
- For the complete safety information for this product, see the full user guide at www.leviton.com

CAUTIONS:

- This product is not intended for life or safety applications.
- Do not install this product in hazardous or classified locations.
- Mount this product inside a suitable fire and electrical enclosure.
- If the collector is connected directly to a source of voltage, the pulse isolator will immediately burn out and become non-responsive.

SCAN TO LEARN MORE

Cat. No. 72D48



Cat. No. 73C48



Cat. No. 73D48



PK-A3387-10-00-0B


INSTALLATION INSTRUCTIONS

ENGLISH

Installation

1. Remove covers.


Screws are provided.



2. Mount.


Use the enclosure as a template.

NOTE: If the meter is not available to use as a template, see the mechanical specifications drawing in the online user guide at www.leviton.com.



3. Connect.

- Conduit fittings
- Conduits
- Blanking plugs



4. Connect voltage leads.


WARNING: RISK OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH. DO NOT ENERGIZE METER WITH THE VOLTAGE COVER REMOVED. CAREFULLY READ AND FOLLOW INSTRUCTIONS.

Connect the voltage leads (L1, L2, L3, and N, as necessary) to the meter, through a dedicated disconnect or circuit breaker.

NOTE: Verify the circuit breaker is marked as the disconnect breaker for the meter.


Wiring the Meter in a Single-Phase Application:

The meter is powered through the voltage between L1 and L2. For Single-Phase installations in which no L2 exists, install a jumper from N to L2. This connection provides power to the meter, maintaining L1-N as the metering voltage reference.




5. Attach high-voltage cover.

NOTE: IP30 TOUCH-SAFE
(with internal cover installed).



6. Connect CT and communications wiring.



Communication Verification

The LCD user interface can be used to quickly confirm the settings required for each combination of interface and protocol. The interface is intuitive and groups commonly associated registers together. Arrows indicate how to move from one menu display to the next. The active menu item is indicated by a blinking character on the LCD. The **ENTER** button is used to select a property, and the **UP** and **DOWN** buttons are used to select among the values supported by the meter.

NOTES:

- Verification includes confirmation of BOTH the physical interface settings (serial or ethernet) and the protocol (Modbus or BACnet) settings.
- Changes to the meter configuration are limited to the communication interface, using the LCD. If additional changes (such as CT type) are required, they must be made using a software interface.


VerifEye S7 Configuration Utilities/Web Application

If your VerifEye model does not include the LCD user interface, or if you prefer to verify the installation using software, then verification is facilitated through the VerifEye S7 Configuration Utilities PC application or the Web App, which shares a common design. For an overview of the VerifEye S7 Configuration Utilities or the VerifEye Web App, refer to the section on Configuration Details in the full user guide.


Pulse Inputs

Series 7200/7300 meters are equipped with 2 pulse inputs. Pulse counting supports accumulation of consumption data from any external meter, using a dry contact (Form A Relay) or open collector outputs. The AcquiSuite Ally pulse inputs are compatible with "low-speed" meters. The pulse duration must exceed 50 m/s in both the logic low and high state, allowing for a maximum input frequency of 10 Hz.

Pulse scaling, resetting, and accumulated values are accessed through registers and are "system" in scope. Refer to the register list, the S7 Configuration Utilities, or the full user guide for more information.



NOTE: A full navigational map is available in the Appendix of the user guide, available at www.leviton.com



WEB VERSION


Wiring

1. a. Wiring in a 3-Wire, Split-Phase Service Panel

WARNING: TO AVOID FIRE, SHOCK, OR DEATH, turn off all power that is supplying the equipment before working on or inside the equipment. Use a properly rated voltage sensing device to confirm that power is off.

WARNING: HIGH VOLTAGES THAT ARE LIFE-THREATENING MAY BE PRESENT. RISK OF ELECTRIC SHOCK.

Configurations shown below are for service types available in the **METER SETUP** drop-down menu.




EXAMPLE LOADS:

- Single-Phase L1-N or L2-N 110 VAC: lighting, appliance, living zone, etc.
- Single-Phase L1-L2 220 VAC: water heater, clothes dryer, equipment with no neutral wire, etc.
- Split-Phase L1-L2 220 VAC: service entrance, equipment with neutral wire, etc.

b. Wiring in a 3-Phase, 4-Wire Service Panel

Configurations shown below are for service types available in the **METER SETUP** drop-down menu.




NOTE: The VerifEye Meter Series uses the Neutral terminal as a voltage reference. For systems without a Neutral conductor, Leviton suggests connecting a Ground wire to this terminal. If the Neutral terminal is left open, Line-to-Line measurements will be accurate, but Line-to-Neutral measurements may not be symmetric. If a Ground wire is connected to the Neutral terminal, <2mA will flow into the Ground wire.

2. Wiring the CTs to the Meter

The diagram to the right shows how to connect CTs to the input terminals on the S7200/7300, for each service type. For service types that are not specifically listed, choose **SINGLE-PHASE** service from the drop-down menu and configure each channel individually. The 3-Phase loads that are illustrated on the left side of the diagram and the Split-Phase loads on the right side of the diagram are shown as **examples only**. Elements are fully interchangeable on the meter.

NOTE: Current and voltage inputs must be installed 'in phase' for accurate readings (e.g., CT1 on Line 1, CT2 on Line 2, etc.). **Orientation is critical.** Ensure that all CTs are properly oriented with the line and load, as marked. **Failure to install CTs in the correct orientation and on the correct phase will lead to inaccurate meter readings.**



FCC COMPLIANCE STATEMENT:

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Any changes or modifications not expressly approved by Leviton Manufacturing Co., could void the user's authority to operate the equipment.

FCC SUPPLIER'S DECLARATION OF CONFORMITY:

Models 72D48 and 73D48 are sold by Leviton Manufacturing Inc. 201 N Service Rd, Melville, NY 11747. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

INDUSTRY CANADA COMPLIANCE STATEMENT:

This device contains license-exempt transmitter/receiver that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

TRADEMARK DISCLAIMER:

Leviton and the Leviton logo are the registered trademarks of Leviton Manufacturing Co., Inc. VerifEye is a Leviton trademark registered in the U.S., Canada, and Mexico. Use herein of third party trademarks, service marks, trade names, brand names and/or product names are for informational purposes only, are/may be the trademarks of their respective owners; such use is not meant to imply affiliation, sponsorship, or endorsement. PhaseChek is a trademark of DENT Instruments. Modbus is a trademark of Schneider Electric USA, Inc. and BACnet is a trademark of ASHRAE

Patents covering this product, if any, can be found on Leviton.com/patents.

FOR CANADA ONLY:

For warranty information and/or product returns, residents of Canada should contact Leviton in writing at **Leviton Manufacturing of Canada ULC** to the attention of the **Quality Assurance Department**, 165 Hymus Blvd, Pointe-Claire (Quebec), Canada H9R 1E9 or by telephone at 1-800-405-5320.

LIMITED 5 YEAR WARRANTY

For Leviton's limited 5 year product warranty, go to www.leviton.com. For a printed copy of the warranty, call 1-800-824-3005.

For Technical Assistance Call: 1-800-824-3005 (USA Only) or 1-800-405-5320 (Canada Only) www.leviton.com

TECHNICAL SPECIFICATIONS

Service Types	Single-Phase; Split-Phase; 3-Phase, 4-Wire (WYE); 3-Phase, 3-Wire (Delta)
Voltage Input	90-346 VAC Line-to-Neutral, 600V Line-to-Line, CAT III
Current Channels	48 channels, 0.525 VAC max, 333 mV CTs, 0-4,000+ Amps (depending on current transducer)
Maximum Current Input	150% of current transducer rating (mV CTs) to maintain accuracy. Measure up to 4000A with Rogowski CTs.
Measurement Type	True RMS, using high-speed digital signal processing (DSP) with continuous sampling
Line Frequency	50-60 Hz
Power	From L1 Phase to L2 Phase. 90-600VAC, RMS, CAT III, 50/60 Hz, 500mA AC Max Use of 12V auxiliary output requires 100 VAC minimum input voltage.
AC Protection	0.5A Fuse 200kA interrupt capacity
Power Out	Unregulated 12VDC output, 200mA, self-resetting fuse
Waveform Sampling	1.8 kHz
Parameter Update Rate	1 second
Measurements	Volts, Amps, kW, kVAR, kVA, aPF, dPF, kW demand, kVA demand, Import (Received) kWh, Export (Delivered) kWh, Net kWh, Import (Received) kVAh, Export (Delivered) kVAh, Net kVAh, Import (Received) kVARh, Export (Delivered) kVARh, Net kVARh, THD, Theta, Frequency. All parameters for each phase and system total.
Accuracy	0.2% ANSI C12.20-2010, Class 0.2
Resolution	Values reported in IEEE-754 single-precision floating point format (32 bit).
Indicators	4-line display, tri-color backlight (PhaseChek™)
Pulse Inputs	VerifEye 48 - 2 Inputs 3.3V sourcing voltage (current limited) to customer dry contact pulse output Maximum Pulse Rate of 10 Hz (50 m/s minimum transition time)
Alarm Output	Voltage Phase Loss Alarm (SPDT Relay - 30 VDC) (only)

Communication


Hardware	RS-485, Ethernet, USB (for configuration only)
Supported Protocols	Modbus RTU or BACnet Master Slave Token Passing protocol (MS/TP) Modbus (using SunSpec IEEE-754 single-precision floating point model) Modbus TCP BACnet IP
Max Communication Length (RS485)	1200 meters total length Belden 1120A or equivalent cable, with Data Range of 100K bits/second or less
RS-485 Loading	1/8 unit
Communication Rate (baud)	Modbus: 9600 (Default), 19200, 38400, 57600, 76800, 115200 BACnet: 9600 (Default), 19200, 38400, 76800
Data Bits	8
Parity	None, Even, Odd
Stop Bit	2, 1
Termination	None provided

Mechanical

Wire Connections and Voltage	12-22 AWG 600 VAC. Voltage connection must be #14 AWG or larger and 600 VAC rated.
Mounting	Enclosure or panel mount
High-Voltage Cover	IP30 (embedded version)
Operating Temperature	-20°C to +60°C (-4°F to 140°F)
Humidity	5% to 95% non-condensing
Enclosure	ABS plastic, 94-V0 flammability rating, connections sized for 1-inch EMT conduit
Dimensions	(L) 33.7 cm x (W) 25.1 cm x (H) 8.0 cm (13.3 in. x 9.8 in. x 3.1 in.) (enclosure version) (L) 26.2 cm x (W) 24.1 cm x (H) 8.0 cm (10.3 in. x 9.5 in. x 3.1 in.) (mounting plate version)
PCBA Dimensions	(L) 21.6 cm x (W) 21.6 cm x (H) 6.4 cm (8.5 in. x 8.5 in. x 2.5 in.)

VerifEye S7 Configuration Utilities Minimum System Requirements

Operating System	Windows® 7, Windows 8, Windows 10, Windows 11
Communications Port	USB or Ethernet connectivity
Certifications	FCC Part 15, Class A



WEB VERSION