

Walldog



Installation Instructions WDOG•WDOGW

Installation Guidelines

For fastening into wallboard or wood, no pre-drilling is required. The anchor is inserted through the fixture and screwed in with an ordinary Phillips screwdriver.



Fastening into concrete, grout-filled or hollow block, brick or plaster requires a 3/16" pre-drilled hole using a carbide tipped drill bit.

