

## EZ METER-PAK® Cross Reference Class 4162



**MAIN DEVICES  
SINGLE PHASE**

**Table 1: Main Circuit Breaker—Single Phase**

Main Circuit Breaker	Amps	AIR (k)	Square D Catalog Number	
			New	Old
<b>Standard</b>	400	65	EZM1400CB	EZM22400NRH
	600	65	EZM1600CB	EZM22600NRH
	800	65	EZM1800CB	EZM22800NRH
	1000	65	EZM11000CB	EZM221000NR
	1200	65	EZM11200CB	EZM221200NR
	1600	65	EZM11600CB	EZM221600NR
<b>Underground Only EUSERC</b>	400	65	EZM1400CBU	EZM22400NURH
	600	65	EZM1600CBU	EZM22600NURH
	800	65	EZM1800CBU	EZM22800NURH
	1000	100	EZM11000CBU	EZM221000NUR
	1200	100	EZM11200CBU	EZM221200NUR
	1600	65	Use EZM11600CB	EZM221600NUR

**Table 2: Main Fusible Switch—Single Phase, 100k AIR**

Main Fusible Switch	Amps	Square D Catalog Number	
		New	Old
<b>Standard</b>	400	EZM1400FS	EZM225NR
	600	EZM1600FS	EZM226NR
	800	EZM1800FS	EZM227NR
	1200	EZM11200FS	New
<b>Underground Only EUSERC</b>	400	EZM1400FSU	EZM225NUR
	600	EZM1600FSU	EZM226NUR
	800	EZM1800FSU	EZM227NUR
	1200	EZM11200FSU	New

**Table 3: Main Lugs Terminal Box—Single Phase**

Main Lugs Terminal Box	Amps	Square D Catalog Number	
		New	Old
<b>Standard</b>	225	Use EZM1400TB	EZM3225TBR
	400	EZM1400TB	New
	800	EZM1800TB	EZM3800TBR
	1600	EZM11600TB	EZM31600TBR

**BRANCH DEVICES  
SINGLE PHASE**

**Table 4: Branch Meter/Circuit Breaker Devices—Residential, Single Phase**

Branch Meter/Circuit Breaker Devices	Amps	No. of Meter Sockets	Square D Catalog Number	
			New	Old
<b>Ring Style 4-Jaw</b>	125	3	EZM113-125	EZM33-125R
	125	4	EZM114-125	EZM34-125R
	125	5	EZM115-125	EZM35-125R
	125	6	EZM116-125 ①	New
	125	6	Use (2) EZM113-125	EZM36125R
	125	8	Use (2) EZM114-125	EZM38125R
	125	10	Use (2) EZM115-125	EZM310125R
	200	2	EZM112-200	New
	200	3	EZM113-200	EZM332R
	200	4	EZM114-200	EZM342R
	200	6	Use (2) EZM113-200	EZM362R
	200	8	Use (2) EZM114-200	EZM382R
<b>Ringless Style No Bypass 5-Jaw</b>	125	3	EZMR113-125	EZMR33-125RJ
	125	4	EZMR114-125	EZMR34-125RJ
	125	5	EZMR115-125	EZMR35-125RJ
	125	6	EZMR116-125 ①	New
	200	2	EZMR112-200	New
	200	3	EZMR113-200	New
	200	4	EZMR114-200	New
<b>Ringless Style Horn Bypass 5-Jaw</b>	125	3	EZMH113-125	EZMR33-125RH
	125	4	EZMH114-125	EZMR34-125RH
	125	5	EZMH115-125	EZMR35-125RH
	125	6	EZMH116-125 ①	New
	200	2	EZMH112-200	New
	200	3	EZMH113-200	New
	200	4	EZMH114-200	New

**Table 5: Branch Meter Devices—Commercial, 5-Jaw, Single Phase**

Branch Meter Devices	Amps	No. of Meter Sockets	Square D Catalog Number	
			New	Old
<b>Ringless Style Lever Bypass</b>	200	1	EZML111-200	New
		2	EZML112-200	EZM432200R
		3	EZML113-200	EZM433200R
		4	EZML114-200	EZM434200R

① Consult your local Square D field office for availability.

**MAIN DEVICES  
THREE PHASE**

**Table 6: Main Circuit Breaker—Three Phase**

Main Circuit Breaker	Amps	AIR (k)	Square D Catalog Number	
			New	Old
<b>Standard</b>	400	65	EZM3400CB	EZM32400NRH
	600	65	EZM3600CB	EZM32600NRH
	800	65	EZM3800CB	EZM32800NRH
	1000	65	EZM31000CB	EZM321000NR
	1200	65	EZM31200CB	EZM321200NR
	1600	65	EZM31600CB	EZM321600NR
<b>Underground Only EUSERC</b>	400	65	EZM3400CBU	EZM32400NURH
	600	65	EZM3600CBU	EZM32600NURH
	800	65	EZM3800CBU	EZM32800NURH
	1000	100	EZM31000CBU	EZM321000NUR
	1200	100	EZM31200CBU	EZM321200NUR
	1600	65	Use EZM31600CB	EZM321600NUR

**Table 7: Main Fusible Switch—Three Phase, 100k AIR**

Main Fusible Switch	Amps	Square D Catalog Number	
		New	Old
<b>Standard</b>	400	EZM3400FS	EZM325NR
	600	EZM3600FS	EZM326NR
	800	EZM3800FS	EZM327NR
	1200	EZM31200FS ①	New
<b>Underground Only EUSERC</b>	400	EZM3400FSU	EZM325NUR
	600	EZM3600FSU	EZM326NUR
	800	EZM3800FSU	EZM327NUR
	1200	EZM31200FSU ①	New

**Table 8: Main Lugs Terminal Box—Three Phase**

Main Lugs Terminal Box	Amps	Square D Catalog Number	
		New	Old
<b>Standard</b>	225	Use EZM3400TB	EZM4225TBR
	400	EZM3400TB	New
	800	EZM3800TB	EZM4800TBR
	1600	EZM31600TB	EZM41600TBR

① Consult your local Square D field office for availability.

**RESIDENTIAL AND  
COMMERCIAL  
BRANCH DEVICES**

**Table 9: Branch Meter/Circuit Breaker Devices  
Residential, 5-Jaw, Three-Phase In and Single-Phase Out**

Branch Meter/Circuit Breaker Devices	Amps	No. of Meter Sockets	Square D Catalog Number	
			New	Old
<b>Ring Style</b>	125	3	EZM313-125	EZM43-125R
	125	4	EZM314-125	EZM44-125R
	125	5	EZM315-125	EZM45-125R
	125	6	EZM316-125 ①	New
	125	6	Use (2) EZM313-125	EZM46125R
	125	8	Use (2) EZM314-125	EZM48125R
	125	10	Use (2) EZM315-125	EZM410125R
	200	2	EZM312-200	New
	200	3	EZM313-200	EZM432R
	200	4	EZM314-200	EZM442R
	200	6	Use (2) EZM313-200	EZM462R
	200	8	Use (2) EZM314-200	EZM482R
<b>Ringless Style No Bypass</b>	125	3	EZMR313-125	EZMR43-125R
	125	4	EZMR314-125	EZMR44-125RA/B/C
	125	5	EZMR315-125	EZMR45-125R
	125	6	EZMR316-125 ①	New
	200	2	EZMR312-200	New
	200	3	EZMR313-200	New
	200	4	EZMR314-200	New
<b>Ringless Style Horn Bypass</b>	125	3	EZMH313-125	EZMR43-125RH
	125	4	EZMH314-125	EZMR44-125RHA/B/C
	125	5	EZMH315-125	EZMR45-125RH
	125	6	EZMH316-125 ①	New
	200	2	EZMH312-200	New
	200	3	EZMH313-200	New
	200	4	EZMH314-200	New

① Consult your local Square D field office for availability.

**Table 10: Branch Meter/Circuit Breaker Devices  
Commercial, 5-Jaw, Three-Phase In and Single-Phase Out**

Branch Meter/Circuit Breaker Devices	Amps	No. of Meter Sockets	Square D Catalog Number	
			New	Old
Ringless Style Lever Bypass	200	2	EZML312-200	EZM542200R
	200	3	EZML313-200	EZM543200R
	200	4	EZML314-200	New
	400	1	EZML311-400	New
	400	2	EZML312-400	EZM542400R
	400	2	Use EZML312-400	EZM542400RY

**Table 11: Branch Meter/Circuit Breaker Devices  
Commercial, 7-Jaw, Three-Phase In and Three-Phase Out**


Branch Meter/Circuit Breaker Devices	Amps	No. of Meter Sockets	Square D Catalog Number	
			New	Old
Ringless Style Lever Bypass	200	1	EZML331-200	EZM741200R
	200	2	EZML332-200	EZM742200R
	200	3	EZML333-200	EZM743200R
	200	4	EZML334-200	EZM744200R
	400	1	EZML331-400	EZM741400R
	400	2	EZML332-400	EZM742400R
Ringless Style No Bypass	200	2	EZMR332-200	EZM742200WBR
		3	EZMR333-200	EZM743200WBR
		4	EZMR334-200	EZM744200WBR

**ACCESSORIES**

**Table 12: EZM Accessories**

Description	Square D Catalog Number	
	New	Old
<b>1<math>\phi</math>3W Bussed Extension, 1200 A</b>	EZM1EXT	EZM31200BER
<b>3<math>\phi</math>4W Bussed Extension, 1200 A</b>	EZM3EXT	EZM41200BER
<b>1<math>\phi</math>3W Bussed Corner Extension, 1200 A (Indoor only)</b>	EZM1CORNER	EZM31200BCS
<b>3<math>\phi</math>4W Bussed Corner Extension, 1200 A (Indoor only)</b>	EZM3CORNER	EZM41200BCS
<b>Fifth Jaw Kit (Residential Sockets only)</b>	5J (1 per kit)	EZM45J (4 per kit)
<b>Slider Type Manual Circuit Closer 125/200 A (Ring Style Residential Sockets only)</b>	MM200MB	EZM200MCCR EZM200MCCLR
<b>Horn Bypass Kit (Residential Sockets only)</b>	MMHB	EZMHB
<b>LEXAN® Meter Socket Cover Plate (Residential Sockets only)</b>	29007	29007
<b>Commercial Meter Socket Cover Plate (EZMR33 and EZML devices only)</b>	RSG-4	RSG-4

Square D Company  
1601 Mercer Road  
Lexington, KY 40511  
(606) 243-8000  
[www.squared.com](http://www.squared.com)

Square D, , EZ METER-PAK, I-LINE, and QO are registered trademarks of Square D Company. All other trademarks are the intellectual property of their respective companies.

Electrical equipment should be serviced only by qualified electrical maintenance personnel. No responsibility is assumed by Square D for any consequences arising out of the use of this material.

Bulletin No. 4162PD9801 December 1998 © 1998 Square D All Rights Reserved.