

NISD.E352710 – EMERGENCY STOP DEVICES

Emergency Stop Devices

See General Information for Emergency Stop Devices

SCHNEIDER ELECTRIC INDUSTRIES S A, DBA TELEMECANIQUE

E352710

8001 Knightdale Blvd
Knightdale, NC 27545 USA

Trademark and/or Tradename:  

Accessories: Legend holders, legend plates, 3D legend plate, metal guards, padlocking kit, Model(s) ZBY or ZBZ followed by any alphanumeric number. Plugs, Cat. No. ZB4-SZ3 and ZB5-SZ3.

Complete device, Emergency stop pushbutton with contact blocks, Model(s) XB4 B and XB5 A followed by S or T, followed by 8 or 9, may be followed by 4, followed by 4 and followed by 2, 4, 41 or 5, may be followed by additional digits.

Component, Contact blocks, Model(s) ZBE, followed by 1 or 2, followed by two digit number, may be followed by 6 or 6P, may be followed by 3, 5 or 9, may be followed by J.

Component, Contact blocks, Model(s) ZEN-L followed by 1121. (@)

Component, Contact Subunit, Model(s) ZB4 - BZ or ZB5 - AZ followed by a three digit or four digit number. (@)

Component, Emergency stop head, Model(s) ZB4 B and ZB5 A followed by S, followed by 8 or 9, followed by 3, 4 or 6, followed by 4, may be followed by additional digits. (@)

Component, Emergency stop head, Model(s) ZB4 B and ZB5 A followed by T or X, followed by 8, followed by 4, may be followed by 4, may be followed by additional digits. (@)

Component, Emergency stop head, Model(s) ZB5 A followed by T, followed by 8, followed by 6, followed by 4, followed by 3 and followed by M. (@)

Component, Emergency stop head with specific marking, Model(s) ZB4 or ZB5, followed by AEQ, followed by four digits. (@)

Contact blocks, Model(s) Cat. No. ZB6, followed by E or Z, followed by 2,3,4,5,6,7,8 or 9, followed by B.

Contact blocks, Model(s) XENT1192, ZB2-BE, followed by 101 or 102

Emergency Stop Devices, Model(s) XAC-A, followed by 20 or 21, followed by 1, 3, 5 or 7, followed by 3 or 4

Emergency Stop Devices, Model(s) XY2CJ followed by L, R, or S, followed by 1, followed by 5, 7, or 9, may be followed by H7 or H29

Emergency Stop Open Type, Illuminated Pushbutton Switches, Model(s) XB5AS86449B4

Emergency Stop Open Type, Non-Illuminated Pushbutton Switches, Model(s) XB5AS84449

Emergency stop pushbutton, Model(s) Cat. No. XB6 AS, followed by 8 or 9, followed by 34, followed by 9B, 2B or 5B

Emergency stop pushbuttons, Model(s) XB7NS or XB7NT, followed by S, followed by 8 or 9, followed by 44 or 4, followed by 2, 4, or 5.

Emergency stop pushbuttons, Model(s) XY2-CH followed by 1, followed by 3 or 4, followed by 1, 2, 3, 4, 5, or 9, followed by 5, 7, or 9, followed by 0, may be followed by H7 or H29, may be followed by TK.

Emergency stop rope pull switches, Model(s) XY2-CE, followed by 1 or 2, followed by A or C, 1, 2, 3, 4, 5 or 9, followed by 5, 7 or 9, followed by 0, 6 or 7, may be followed by H7 or H7TK.

Emergency stop rope pull switches, Model(s) XY2CED, followed by A, B, C or D, followed by 1, 2, 3, 4, 5 or 9, followed by 9, followed by 0, 6 or 7, may be followed by H7, H7TK, EX or Sxx, where xx is two digits.

Enclosed device, Emergency stop unit, Model(s) XAL K, followed by 1, followed by 7, 8 or 9, followed by 8, may be followed by E, F or G, followed by H7. (@)

Illuminated Safety Actuator, Model(s) XALK84W or XALK178W followed by one digit, followed by B or M, may be followed by three digits, followed by E or G, followed by H7. (@)

Illuminated Safety Actuator, Emergency stop pushbutton operating heads, Model(s) ZB5AS84W, followed by one digit, followed by B, G or M. (@)

Illuminated Safety Actuator, Emergency stop pushbutton with contact blocks, complete device, Model(s) XB5AS84W followed by 3 or 4, followed by B, followed by 5 or 41.

Illuminated Safety Actuator, Illuminated ring for emergency stop pushbuttons, Model(s) ZBY9W followed by one digit, followed by B, G or M, followed by three or four digits.

Operating heads, Model(s) Cat. No. ZB6-AS followed by 8 or 9, followed by 34

Operating heads, Model(s) ZA2-BS, followed by 8 or 9, followed by 3 or 4, followed by 4.

Pendant Empty Enclosure Stations, Model(s) XAC-A followed by 02, 03, 04, 05, 06, 08, or 12, followed by H7.

Pendant Push Button Stations, Model(s) XAC-A, followed by a one or two digit number, followed by 71, 81, 91, or 92 or may be followed by ? combination of S and D (up to three letters), may be followed by 2, 3, 4, 5, may be followed by one digit, followed by H7.

Safety Actuator label, Model(s) ZBY8L, followed by three or four digits.

(@) - Note: A minimum of 1 N.C. contact is required; additional N.O. or N.C contacts for multiple contact installations are optional.

Last Updated on 2019-09-04

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL's Follow-Up Service. Only those products bearing the UL Mark should be considered to be Certified and covered under UL's Follow-Up Service. Always look for the Mark on the product.

UL permits the reproduction of the material contained in the Online Certification Directory subject to the following conditions: 1. The Guide Information, Assemblies, Constructions, Designs, Systems, and/or Certifications (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from the Online Certifications Directory with permission from UL" must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "© 2019 UL LLC"