

# Programmable Controllers for Use in Hazardous Locations Certified for Canada

## COMPANY

SCHNEIDER ELECTRIC JAPAN HOLDINGS LTD.

2-15-6, SHIBAURA

MINATO-KU, Tokyo 108-0023 Japan

E210412

Trademark and/or Tradename: "E486185",  Pro-face Schneider Electric Pro-face

Note: For additional marking information, refer to the [Guide Information Page](#).

**Associated Apparatus, Non-hazardous location use, Bus module with PCI or PCIe bus**, Model(s): HMIYPCI161, HMIYPCI261, HMIYPCIA61, HMIYPCIC61, PFXZPSEUPCI11, PFXZPSEUPCI21, PFXZPSEUPCIA1, PFXZPSEUPCIC1

**Associated Apparatus, Non-hazardous location use, Bus modules with PCI or PCIe bus**, Model(s): HMIYPCI161, HMIYPCI261, HMIYPCIA61, HMIYPCIC61, PFXZPSEUPCI11, PFXZPSEUPCI21, PFXZPSEUPCIA1, PFXZPSEUPCIC1

**Associated Apparatus, Non-hazardous location use, CFast adapter**, Model(s): HMIYADCFAST61, PFXZPSSCAD2

**Associated Apparatus, Non-hazardous location use, CFast adapters**, Model(s): HMIYADCFAST61, PFXZPSSCAD2

**Associated Apparatus, Non-hazardous location use, CFast memory**, Model(s): HMIYCFAXx, HMIYCFAXx, PFXZCDSCCFAX(x)1, PFXZCDSCCFAX(x)1

**Associated Apparatus, Non-hazardous location use, Class I, Division 2, Groups A, B, C and D**, Model(s): PFXZPP2IUUFAN2

**Associated Apparatus, Non-hazardous location use, Connecting cables**, Model(s): PFXZPSCBUP32, PFXZPSCBUP32

**Associated Apparatus, Non-hazardous location use, Fan kits**, Model(s): HMIYPFKT061, HMIYPFKT061, PFXZPP1IUUFAN2, PFXZPP1IUUFAN2, PFXZPP2IUUFAN2

**Associated Apparatus, Non-hazardous location use, Front panel mounted programmable controller assemblies**, Model(s): HMIPCCP16xxxxxxxxxxx, HMIPCCx1Bxxxxxxxxxxx, HMIPxx6xxxxx(y), PFXPF16xxxxxxxxxxx, PFXPF16xxxxxxxxxxx, PFXPP16xxxxxxxxxxx

**Associated Apparatus, Non-hazardous location use, Front Panel mounted Programmable Controller Assemblies**, Model(s): HMIPCCP16xxxxxxxxxxx, HMIPCCx1Bxxxxxxxxxxx, HMIPxx6xxxxx(y), PFXPP16xxxxxxxxxxx

**Associated Apparatus, Non-hazardous location use, Hard disk drive**, Model(s): HMIYHDDxxx61, PFXZPSSCHDDxx2

**Associated Apparatus, Non-hazardous location use, Hard disk drives**, Model(s): HMIYHDDxxx61, PFXZPSSCHDDxx2

**Associated Apparatus, Non-hazardous location use, Interface board with battery control module**, Model(s): HMIYPUISINT61, PFXZPSIUUPM2

**Associated Apparatus, Non-hazardous location use, Interface board with RS485 bus**, Model(s): HMIYPINSL61, PFXZPSIUUCMR42

**Associated Apparatus, Non-hazardous location use, Interface board with SRAM**, Model(s): HMIYPINSRAM61, PFXZPSIUSR2

**Associated Apparatus, Non-hazardous location use, Interface boards with battery control module**, Model(s): HMIYPUISINT61, PFXZPSIUUPM2

**Associated Apparatus, Non-hazardous location use, Interface boards with RS485 bus**, Model(s): HMIYPINSL61, PFXZPSIUCMR42

**Associated Apparatus, Non-hazardous location use, Interface boards with SRAM**, Model(s): HMIYPINSRAM61, PFXZPSIUSR2

**Associated Apparatus, Non-hazardous location use, Memory module**, Model(s): HMIYPRAM302061, HMIYPRAM304061, HMIYPRAM308061, PFXZPSD3x1

**Associated Apparatus, Non-hazardous location use, Memory modules**, Model(s): HMIYPRAM302061, HMIYPRAM304061, HMIYPRAM308061, PFXZPSD3x1

**Associated Apparatus, Non-hazardous location use, power supplies**, Model(s): HMIYPMAC61, PFXZPSPUAC1

**Associated Apparatus, Non-hazardous location use, Power supply**, Model(s): HMIYPMAC61

**Associated Apparatus, Non-hazardous location use, Power supply & Connector**, Model(s): PFXZPSPUAC1

**Associated Apparatus, Non-hazardous location use, Power supply connector**, Model(s): PFXZPSCNAC2

**Associated Apparatus, Non-hazardous location use, Power supply connectors**, Model(s): PFXZPSCNAC2

**Associated Apparatus, Non-hazardous location use, Programmable controller modules, TWIDO**, Model(s): EXM-AMM6HT

**Associated Apparatus, Non-hazardous location use, Programmable logic controllers advantys OTB optimized terminal block**, Model(s): HTB1CODM9LP

**Associated Apparatus, Non-hazardous location use, Retaining clip**, Model(s): PFXZPPAF10P2

**Associated Apparatus, Non-hazardous location use, Retaining clips**, Model(s): PFXZPPAF10P2

**Associated Apparatus, Non-hazardous location use, Slide-in compact adapter**, Model(s): HMIYADSLIDEIN61, PFXZPSSAD2

**Associated Apparatus, Non-hazardous location use, Slide-in compact adapters**, Model(s): HMIYADSLIDEIN61, PFXZPSSAD2

**Associated Apparatus, Non-hazardous location use, Slide-in DVD**, Model(s): HMIYDRDVDRW61, PFXZPSSSMD2

**Associated Apparatus, Non-hazardous location use, Slide-in DVDs**, Model(s): HMIYDRDVDRW61, PFXZPSSSMD2

**Associated Apparatus, Non-hazardous location use, Solid state drive**, Model(s): HMIYSDDxxx61, PFXZPSSCSDx(x)2

**Associated Apparatus, Non-hazardous location use, Solid state drives**, Model(s): HMIYSDDxxx61, PFXZPSSCSDx(x)2

**Associated Apparatus, Non-hazardous location use, Spare filter**, Model(s): PFXZPP1FTFAN2, PFXZPP2FTFAN2

**Associated Apparatus, Non-hazardous location use, Spare filters**, Model(s): PFXZPP1FTFAN2, PFXZPP2FTFAN2

**Associated Apparatus, Non-hazardous location use, UPS Battery unit**, Model(s): HMIYUPSKT61, PFXZPSEUUPB2

**Associated Apparatus, Non-hazardous location use, UPS battery units**, Model(s): HMIYUPSKT61, PFXZPSEUUPB2

**Class I, Division 2, Group A, B, C and D, Accessories, extension communication cables**, Model(s): PFXZXMADSM31, PFXZXMADSM51

**Class I, Division 2, Group A, B, C and D, Accessories, extension communication cables**, Model(s): HMI-ZSURDP may be followed by 5, may be followed by three alphanumeric digits

**Class I, Division 2, Group A, B, C and D, Accessory Box Unit, Open-Type**, Model(s): HMIG2U , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Accessory Box Unit, Open-Type**, Model(s): PFXSP5B00 , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Accessory box units, open-type**, Model(s): HMIG3U , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Accessory box units, open-type**, Model(s): HMIG5U , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Accessory box units, open-type**, Model(s): HMIG5U2 , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Accessory box units, open-type**, Model(s): PFXSP5B10 , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Accessory box units, open-type**, Model(s): PFXSP5B40 , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Accessory box units, open-type**, Model(s): PFXSP5B41 , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Accessory CANopen Master Unit, Open-type**, Model(s): PFXZCHEUCAM1 , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Accessory CANopen Slave Unit, Open-type**, Model(s): HMIZGCAN , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Accessory CANopen Slave Unit, Open-type**, Model(s): PFXZCDEUCA1 , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Accessory CANopen units**, Model(s): PFXZCDEUCA1

**Class I, Division 2, Group A, B, C and D, Accessory CANopen units, for use with Graphic Display Models 3481401-01, -02 and 3583401-01, -02, -03, -04, -11, -12, -13, -14**, Model(s): 3610007-01, XBTZGCCAN

**Class I, Division 2, Group A, B, C and D, Accessory enclosure kits**, Model(s): HMIZECOV1, HMIZECOV2, HMIZECOV4, HMIZECOV5, HMIZECOV6, PFXZCBOP101, PFXZCBOP121, PFXZCBOP41, PFXZCBOP61, PFXZCBOP71, PFXZCDCVUS1

**Class I, Division 2, Group A, B, C and D, Accessory environment covers**, Model(s): HMIZDCOV5, HMIZDCOV6, HMIZDCOV7, PFXZCDOP101, PFXZCDOP121, PFXZCDOP151

**Class I, Division 2, Group A, B, C and D, Accessory FLEX NETWORK Master Unit, Open-type**, Model(s): PFXZCHEUFN1 , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Accessory Multi Display Adaptor, Open-type**, Model(s): HMIZMDARX , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Accessory Multi Display Adaptor, Open-type**, Model(s): PFXZCDADEXR1 , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Accessory multi display adaptors, open-type**, Model(s): PFXZCDADEXR1

**Class I, Division 2, Group A, B, C and D, Accessory Profibus Unit, Open-type**, Model(s): HMIZGPDP , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Accessory Profibus Unit, Open-type**, Model(s): PFXZCDEUPF1 , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Accessory profibus units, open type**, Model(s): PFXZCDEUPF1

**Class I, Division 2, Group A, B, C and D, Basic Display Module 4Wide**, Model(s): HMISTM62# # - Any letter(s) and/or number(s) or Blank HMI STM 6 X X # I II III IV V VI I : Schneider Brand Name II: Model name STM III: Series name 6 IV: Display size: 2 4"W 4 7"W V: Interface/type 00 Additional rear module HMISTM6B blank Display module only VI: optional suffix for customization (no impact on basic safety)

**Class I, Division 2, Group A, B, C and D, Basic Display Module 4Wide**, Model(s): PFXSTM62TP# # - Any letter(s) and/or number(s) or Blank PFX STM 6 X X # I II III IV V VI I : Proface Brand Name II: Model name STM III: Series name 6 IV: Display size: 2 4"W 4 7"W V : Interface TP Display module only 00WAD Additional rear module PFXSTM6B VI: optional suffix for customization (no impact on basic safety)

**Class I, Division 2, Group A, B, C and D, Basic Display Module 7Wide**, Model(s): HMISTM64# # - Any letter(s) and/or number(s) or Blank HMI STM 6 X X # I II III IV V VI I: Schneider Brand Name II: Model name STM III: Series name 6 IV: Display size: 2 4"W 4 7"W V: Interface/type 00 Additional rear module HMISTM6B blank Display module only VI: optional suffix for customization (no impact on basic safety)

**Class I, Division 2, Group A, B, C and D, Basic Display Module 7Wide**, Model(s): PFXSTM64TP# # - Any letter(s) and/or number(s) or Blank PFX STM 6 X X # I II III IV V VI I: Proface Brand Name II: Model name STM III: Series name 6 IV: Display size: 2 4"W 4 7"W V: Interface TP Display module only 00WAD Additional rear module PFXSTM6B VI: optional suffix for customization (no impact on basic safety)

**Class I, Division 2, Group A, B, C and D, Basic HMI Gateway**, Model(s): HMISTM6BOX# # - Any letter(s) and/or number(s) or Blank HMI STM 6 X X # I II III IV V VI I: Schneider Brand Name II: Model name STM III: Series name 6 IV: Display size: 2 4"W 4 7"W V: Interface/type 00 Additional rear module HMISTM6B blank Display module only VI: optional suffix for customization (no impact on basic safety)

**Class I, Division 2, Group A, B, C and D, Basic HMI Gateway**, Model(s): PFXSTM6B00D# # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Basic Modular HMI 4Wide**, Model(s): HMISTM6200# # - Any letter(s) and/or number(s) or Blank HMI STM 6 X X # I II III IV V VI I: Schneider Brand Name II: Model name STM III: Series name 6 IV: Display size: 2 4"W 4 7"W V: Interface/type 00 Additional rear module HMISTM6B blank Display module only VI: optional suffix for customization (no impact on basic safety)

**Class I, Division 2, Group A, B, C and D, Basic Modular HMI 4Wide**, Model(s): PFXSTM6200WAD# # - Any letter(s) and/or number(s) or Blank PFX STM 6 X X # I II III IV V VI I: Proface Brand Name II: Model name STM III: Series name 6 IV: Display size: 2 4"W 4 7"W V: Interface TP Display module only 00WAD Additional rear module PFXSTM6B VI: optional suffix for customization (no impact on basic safety)

**Class I, Division 2, Group A, B, C and D, Basic Modular HMI 7Wide**, Model(s): HMISTM6400# # - Any letter(s) and/or number(s) or Blank HMI STM 6 X X # I II III IV V VI I: Schneider Brand Name II: Model name STM III: Series name 6 IV: Display size: 2 4"W 4 7"W V: Interface/type 00 Additional rear module HMISTM6B blank Display module only VI: optional suffix for customization (no impact on basic safety)

**Class I, Division 2, Group A, B, C and D, Basic Modular HMI 7Wide**, Model(s): PFXSTM6400WAD# # - Any letter(s) and/or number(s) or Blank HMI STM 6 X X # I II III IV V VI I: Schneider Brand Name II: Model name STM III: Series name 6 IV: Display size: 2 4"W 4 7"W V: Interface/type 00 Additional rear module HMISTM6B blank Display module only VI: optional suffix for customization (no impact on basic safety)

**Class I, Division 2, Group A, B, C and D, Basic Rear Module**, Model(s): HMISTM6B# # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Basic Rear Module**, Model(s): PFXSTM6B# # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Battery control modules**, Model(s): PFXZPBUIUPM1 (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) - Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) - Where x = letters or numbers, y = W or V. (c) - Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Battery housings**, Model(s): PFXZPSEUUPB1 (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) - Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) - Where x = letters or numbers, y = W or V. (c) - Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Color graphic panels**, Model(s): 3280024-02, 3280024-04, 3280024-06, 3280024-12, 3280024-14, 3280024-16, 3280024-22, 3280024-24, 3280035-41, 3280035-51, 3280035-71, 3481401-01, 3481401-02, 3482001-51, 3482001-52, 3482001-55, 3482001-61, 3482001-65, 3482001-75, 3581301-02, 3581301-04, 3581902-33, 3581902-51

**Class I, Division 2, Group A, B, C and D, Communication cables, "Series Magelis"**, Model(s): HMIZ or XBTZ followed by 3 to 5 letters and digits.

**Class I, Division 2, Group A, B, C and D, compact flash memory**, Model(s): HMIYCF50211 (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) - Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) - Where x = letters or numbers, y = W or V. (c) - Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, compact flash memory**, Model(s): HMIYCFS0411 (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, compact flash memory**, Model(s): HMIYCFS0811 (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Connecting cables**, Model(s): PFXZPSCBUP3 (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, DC Power Supply Adaptor**, Model(s): HMIZMDAEX , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, DC Power Supply Adaptor**, Model(s): PFXZCDADEXP1 , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Display Adapter (Human-Machine Interfaces)**, Model(s): FXPA2xxxAXxxxxxxx, HMIDADP11xxxxxxx, HMIPCCA2xxxAXxxxxxxx, HMIPCCA2xxxDxxxxxxx, PFXPA2xxxDxxxxxxx, PFXZPPDADDP2xxxxxxx

**Class I, Division 2, Group A, B, C and D, Dock Station Adapter**, Model(s): HMIZM6DSA# # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Dock Station Adapter**, Model(s): PFXZCM6DSA# # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, DVD roms**, Model(s): HMIYDRDVRW11

**Class I, Division 2, Group A, B, C and D, DVD roms**, Model(s): PFXZPSSSMD1 (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, EZ LAN Adapter**, Model(s): PFXZCGEUE1

**Class I, Division 2, Group A, B, C and D, Fan kits**, Model(s): HMIYPFKT01, HMIYPFKT21, PFXZPP0IUFAN1, PFXZPP2IUFAN1

**Class I, Division 2, Group A, B, C and D, Filter modules**, Model(s): HMIYLFIMAR11 (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Filter modules**, Model(s): PFXZFTPND1 (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Flat panel displays**, Model(s): 3580406-11

**Class I, Division 2, Group A, B, C and D, Flat panel displays**, Model(s): HMIDID7DT0 , USB port in the front of the flat panel display, provides non-incendive field wirings to Class I, Division 2, Groups A, B, C and D Hazardous Locations when connected in accordance with installation drawing 35016429.

**Class I, Division 2, Group A, B, C and D, Flat panel displays, provides non-incendive field wiring to Class I, Division 2, Groups A, B, C and D, Hazardous Locations in accordance with installation drawing 35016429**, Model(s): 3620004-01

**Class I, Division 2, Group A, B, C and D, Flat Panel Interface**, Model(s): HMIDID64DTD1 , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Flat Panel Interface**, Model(s): HMIDID73DTD1 , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Flat Panel Interface**, Model(s): PFXFP5600TPD , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Flat Panel Interface**, Model(s): PFXFP5660TPD , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Flat Panel Interface**, Model(s): PFXFP5700TPD , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Front Module**, Model(s): PFXXM4200TP, PFXXM4300TP

**Class I, Division 2, Group A, B, C and D, Front Module, "Series Magelis"**, Model(s): HMI followed by -S65, -S85, may be followed by a three-alphanumeric digit number.

**Class I, Division 2, Group A, B, C and D, graphic adapters**, Model(s): HMIYRAIDD025011

**Class I, Division 2, Group A, B, C and D, Graphic displays**, Model(s): HMIGTO1300\*, HMIGTO1310\*, HMIGTO2300\*, HMIGTO2310\*, HMIGTO2315\*, HMIGTO3510\*, HMIGTO4310\*, HMIGTO5310\*, HMIGTO5315\*, HMIGTO6310\*, HMIGTO6315\*, PFXGP4201TAD\*, PFXGP4201TADW\*, PFXGP4203TAD\*, PFXGP4301TAD\*, PFXGP4301TADS\*, PFXGP4301TADW\*, PFXGP4303TAD\*, PFXGP4401TAD\*, PFXGP4401WADW\*, PFXGP4501TAA\*, PFXGP4501TAD\*, PFXGP4501TADS\*, PFXGP4501TADW\*, PFXGP4501TMA\*, PFXGP4501TMD\*, PFXGP4503TAD\*, PFXGP4601TAA\*, PFXGP4601TAD\*, PFXGP4601TADS\*, PFXGP4601TMA\*, PFXGP4601TMD\*, PFXGP4603TAD\*

**Class I, Division 2, Group A, B, C and D, hard disks**, Model(s): HMIYADSLIDEIN11 (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, hard disks**, Model(s): HMIYHDD025011 (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, hard disks**, Model(s): HMIYRAIDPCI11 (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): HMIDM6600TM# # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): HMIDM6700TM# # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): HMIDM6700WC# # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): HMIDM6800WC# # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): HMIDT351 , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): HMIDT542 , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): HMIDT551 , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): HMIDT642 , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): HMIDT643 , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): HMIDT651 , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): HMIDT732 , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): HMIDT752 , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): HMIDT952 , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): PFXDM6600TM# # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): PFXDM6700TM# # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): PFXDM6700WC# # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): PFXDM6800WC# # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): PFXSP5400WAD , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): PFXSP5500TPD , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): PFXSP5500WAD , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): PFXSP5600TPD , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): PFXSP5600WAD , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): PFXSP5660TPD , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): PFXSP5700TPD , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): PFXSP5700WCD , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): PFXSP5800WCD , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): PFXST6600WADE0# #:May be followed by one to three alphanumeric characters, where # might by any letter(s) and/or number(s) or Blank, not safety relevant.

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): PFXSTC6300TADDC# where # might by any letter(s) and/or number(s) or Blank, not safety relevant.

**Class I, Division 2, Group A, B, C and D, Human Machine Interface**, Model(s): PFXSTC6300TADDK# where # might be any letter(s) and/or number(s) or Blank, not safety relevant.

**Class I, Division 2, Group A, B, C and D, Human Machine Interface, Open-Type**, Model(s): PFXSP5600TAD , may be followed by any letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, human machine interfaces**, Model(s): HMIGK2310 , may be followed by any one to three letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, human machine interfaces**, Model(s): HMIGK5310 , may be followed by any one to three letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, human machine interfaces**, Model(s): PFXGP4311KTAD , may be followed by any one to three letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, human machine interfaces**, Model(s): PFXGP4511KTAD , may be followed by any one to three letter(s) and/or number(s).

**Class I, Division 2, Group A, B, C and D, Illuminated switch units**, Model(s): HMIZRAI, PFXZCCEUSG1

**Class I, Division 2, Group A, B, C and D, Industrial Box PC and displays**, Model(s): PFXPP2 followed by 12 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Industrial Box PC and displays**, Model(s): PFXPU2 followed by 12 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Industrial Controller, Box type**, Model(s): Box type, model PFXP6 or HMIP6 , followed by A, B or D, followed by B, followed by B, followed by 0, followed by N, followed by 0, A, 2, 3 or 4, followed by 0, 1, 2, 3, 4 or S, followed by @, followed by N, H, J or K, followed by @, followed by #. Note @ – Any alphanumeric Note # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Industrial Controller, Panel type**, Model(s): Panel type, model PFXP6 or HMIP6 , followed by A, B or D, followed by 6, 7, D, E, F, G or A, followed by B, followed by 0, followed by N, followed by 0, A, 2, 3 or 4, followed by 0, 1, 2, 3, 4 or S, followed by @, followed by N, H, J or K, followed by @, followed by #. Note @ – Any alphanumeric. Note # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Interface boards**, Model(s): HMIYBINSL11 (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Interface boards**, Model(s): HMIYINDVIRGB11 (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Interface boards**, Model(s): PFXZPBIUCMR41 (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Interface boards**, Model(s): PFXZPSIUDV1 (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Monochrome graphic panels**, Model(s): 3280024-32, 3280024-34, 3581902-12

**Class I, Division 2, Group A, B, C and D, Numpad units**, Model(s): HMIZKB1, PFXZCCEUKB1

**Class I, Division 2, Group A, B, C and D, Open-type graphic displays**, Model(s): 3580205-01, 3580205-02, 3580205-03, 3580205-04, 3583401-01, 3583401-02, 3583401-03, 3583401-04, 3583401-11, 3583401-12, 3583401-13, 3583401-14, 3680701-01, 3680701-02, 3680701-03, XBTGC2330T, XBTGC2330U

**Class I, Division 2, Group A, B, C and D, Open-type graphic panels**, Model(s): 3910017-01, 3910017-02, 3910017-03, 3910017-04, 3910017-05, 3910017-06, 3910017-07, 3910017-08, 3910017-11, 3910017-12, HMISTO501, HMISTO511, HMISTO512, HMISTO531, HMISTO532

**Class I, Division 2, Group A, B, C and D, Open-type human machine interfaces, "PFXGP4110 series"**, Model(s): HMISTO705#  
(Where "\*" may be any letter or number. "#" may be any character(s) and/or number(s) or blank.)

**Class I, Division 2, Group A, B, C and D, Open-type human machine interfaces, "PFXGP4110 series"**, Model(s): HMISTO715#  
(Where "\*" may be any letter or number. "#" may be any character(s) and/or number(s) or blank.)

**Class I, Division 2, Group A, B, C and D, Open-type human machine interfaces, "PFXGP4110 series"**, Model(s): HMISTO735#  
(Where "\*" may be any letter or number. "#" may be any character(s) and/or number(s) or blank.)

**Class I, Division 2, Group A, B, C and D, Open-type human machine interfaces, "PFXGP4110 series"**, Model(s): PFXGP4114T\*D# (Where "\*" may be any letter or number. "#" may be any character(s) and/or number(s) or blank.)

**Class I, Division 2, Group A, B, C and D, Open-type human machine interfaces, "PFXGP4110 series"**, Model(s): PFXGP4115T\*D# (Where "\*" may be any letter or number. "#" may be any character(s) and/or number(s) or blank.)

**Class I, Division 2, Group A, B, C and D, Open-type human machine interfaces, "PFXGP4110 series"**, Model(s): PFXGP4116T\*D# (Where "\*" may be any letter or number. "#" may be any character(s) and/or number(s) or blank.)

**Class I, Division 2, Group A, B, C and D, Open-type programmable controllers, "SP5000 Series"**, Model(s): PFXSP5700WCD, PFXSP5800WCD

**Class I, Division 2, Group A, B, C and D, Open-type programmable controllers, graphic operator interface, for use in Class I, Division 2 Groups A, B, C and D when installed per control drawing no. HRB78717, "SP5000 Series"**, Model(s): PFXFP5600TPD (c), PFXFP5660TPD (c), PFXFP5700TPD (c), PFXSP5500TPD (c), PFXSP5600TPD (c), PFXSP5660TPD (c), PFXSP5700TPD (c)

**Class I, Division 2, Group A, B, C and D, open-type, panel-mounted operator panel control system**, Model(s): PFXST6300TAD#  
where # might by any letter(s) and/or number(s) or Blank, not safety relevant.

**Class I, Division 2, Group A, B, C and D, open-type, panel-mounted operator panel control system**, Model(s): PFXST6500TAD#  
where # might by any letter(s) and/or number(s) or Blank, not safety relevant.

**Class I, Division 2, Group A, B, C and D, Panel computers, provide non-incendive field wirings to Class I, Division 2, Groups A, B, C and D, Hazardous Locations in accordance with installation drawing 35016429**, Model(s): 3580301-01, 3580301-02, 3580301-03, 3580301-11, 3580301-12, 3580301-13

**Class I, Division 2, Group A, B, C and D, Programmable Controller**, Model(s): HMIFP6500WCD# Note # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Programmable Controller**, Model(s): HMIFP6600TMD# Note # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Programmable Controller**, Model(s): HMIFP6600WCD# Note # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Programmable Controller**, Model(s): HMIFP6700TMD# Note # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Programmable Controller**, Model(s): HMIFP6700WCD# Note # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Programmable Controller**, Model(s): HMIFP6800WCD# Note # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Programmable Controller**, Model(s): HMIFP6900WCD# Note # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Programmable Controller**, Model(s): PFXFP6500WCD# Note # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Programmable Controller,** Model(s): PFXFP6600TMD# Note # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Programmable Controller,** Model(s): PFXFP6600WCD# Note # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Programmable Controller,** Model(s): PFXFP6700TMD# Note # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Programmable Controller,** Model(s): PFXFP6700WCD# Note # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Programmable Controller,** Model(s): PFXFP6800WCD# Note # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Programmable Controller,** Model(s): PFXFP6900WCD# Note # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Programmable controller assemblies,** Model(s): 5P82:Assembly-10, HMIGTW5354, HMIGTW7354, HMIGTW73545, HMIPCCx170B (a), HMIPCCx170C (a), HMIPCCx172B (a), HMIPCCx172C (a), HMIPCCx17AB (a), HMIPCCx17AC (a), HMIPCCx180B (a), HMIPCCx180C (a), HMIPCCx182B (a), HMIPCCx182C (a), HMIPCCx18AB (a), HMIPCCx18AC (a), HMIPPe7f0gh1 (&), HMIPPe7f2gh1 (&), HMIPPe9f0gh1 (&), HMIPPe9f2gh1 (&), HMIPTe7f2gh1 (&), HMIPUe7f0gh1 (&), HMIPUe7f2gh1 (&), HMIPUe9f0gh1 (&), HMIPUe9f2gh1 (&), HMIPVC7D0xx1, HMIPWC5D0E01, HMIPWC7D0E01, HMIYUPSKT11, PFXPx170B (#), PFXPx170C (#), PFXPx171C (#), PFXPx172B (#), PFXPx172C (#), PFXPx17AB (#), PFXPx17AC (#), PFXPx180B (#), PFXPx180C (#), PFXPx181B (#), PFXPx181C (#), PFXPx182B (#), PFXPx182C (#), PFXPx18AB (#), PFXPx18AC (#)

**Class I, Division 2, Group A, B, C and D, Programmable controller assemblies,** Model(s): HMI BPxDD2yz1 (^) (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Programmable controller assemblies,** Model(s): HMI BPxDD5yz1 (^) (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Programmable controller assemblies,** Model(s): HMI BUxND1yz1 (^) (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Programmable controller assemblies,** Model(s): HMI BUxND2yz1 (^) (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Programmable controller assemblies,** Model(s): HMIBP0DB2001A (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Programmable controller assemblies,** Model(s): HMIBP0DD2001 (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Programmable controller assemblies,** Model(s): HMIBPFDB2P01 (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Programmable controller assemblies,** Model(s): HMIBPHDB2P01 (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x =



**Class I, Division 2, Group A, B, C and D, Programmable controller assemblies,** Model(s): PFXPB1B1C (%) (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Programmable controller assemblies,** Model(s): PFXPB1B2B (%) (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Programmable controller assemblies,** Model(s): PFXPB1B2C (%) (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Programmable controller assemblies,** Model(s): PFXPB1B5B (%) (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Programmable controller assemblies,** Model(s): PFXPB1B5C (%) (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Programmable controller assemblies,** Model(s): PFXPB1BAB (%) (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Programmable controller assemblies,** Model(s): PFXPB1BAC (%) (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Programmable controller assemblies,** Model(s): PFXPB1BBB (%) (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Programmable controller assemblies,** Model(s): PFXPB1BBC (%) (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Programmable controller assemblies,** Model(s): PFXPx170Axxxx0 (@) (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Programmable Controller for use in HazLoc,** Model(s): Box type, Advanced type, model PFXP6 or HMIP6 followed by 5, 7 or C, followed by B, followed by A or D, followed by E, M, P or 0, followed by F or N (Note\$), followed by one digit number of 0 to 8, followed by one digit number of 5 to 8 or 0, followed by @, followed by B, C, D, E, F, G or N, followed by @, followed by # Note \$ - Should be followed by F for models with HDD for Storage and/or with Accessory Optional Interface for EtherCAT, Note @ - Any alphanumeric, # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Programmable Controller for use in HazLoc,** Model(s): Box type, Standard type, model PFXP6 or HMIP6 followed by 3, followed by B, followed by 1 or 2, followed by 0, followed by N, followed by one digit number of 0 to 8, followed by one digit number of 5 to 8 or 0, followed by @, followed by B, C, D, E, F, G or N, followed by @, followed by # Note @ - Any alphanumeric, # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Programmable Controller for use in HazLoc,** Model(s): HMIDM6500WC# # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Programmable Controller for use in HazLoc**, Model(s): HMIDM6600WC# # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Programmable Controller for use in HazLoc**, Model(s): HMIDM6900WC# # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Programmable Controller for use in HazLoc**, Model(s): Panel type, Advanced type, model PFXP6 or HMIP6 followed by 5, 7 or C, followed by 6, 7, E, F, G, A, followed by A or D, followed by E, M, P or O, followed by F or N (Note\$), followed by one digit number of 0 to 8, followed by one digit number of 5 through 8 or 0, followed by @, followed by B, C, D, E, F, G or N, followed by @, followed by # Note \$ - Should be followed by F for models with HDD for Storage and/or with Accessory Optional Interface for EtherCat, Note @ - Any alphanumeric, # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Programmable Controller for use in HazLoc**, Model(s): Panel type, Standard type, model PFXP6 or HMIP6 followed by 3, followed by 6, 7, D, E, F, G, A, followed by 1 or 2, followed by 0, followed by N, followed by one digit number of 0 to 8, followed by one digit number of 5 to 8 or 0, followed by @, followed by B, C, D, E, F, G or N, followed by @, followed by # Note @ - Any alphanumeric, # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Programmable Controller for use in HazLoc**, Model(s): PFXDM6500WC# # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Programmable Controller for use in HazLoc**, Model(s): PFXDM6600WC# # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Programmable Controller for use in HazLoc**, Model(s): PFXDM6900WC# # - Any letter(s) and/or number(s) or Blank

**Class I, Division 2, Group A, B, C and D, Programmable Controllers for HazLoc, "SP5000X Series"**, Model(s): HMIDT35X#, HMIDT65X#, HMIDT75X#, HMIG3X#, HMIZXJ19#, PFXSP5490WAD#, PFXSP5690WAD#, PFXSP5790WAD#, PFXSP5B90#, PFXZCHEUJ1#

**Class I, Division 2, Group A, B, C and D, Programmable Controllers for Use in HazLoc**, Model(s): HMIYBFKT11 (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Programmable Controllers for Use in HazLoc**, Model(s): HMIYBFKT21 (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Programmable Controllers for Use in HazLoc**, Model(s): HMIYBFKT51 (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Programmable Controllers for Use in HazLoc**, Model(s): PFXZPB1IUFAN1 (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Programmable Controllers for Use in HazLoc**, Model(s): PFXZPB2IUFAN1 (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Programmable Controllers for Use in HazLoc**, Model(s): PFXZPB5IUFAN1 (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Programmable Controllers for Use in HazLoc, "SP5000 Series"**, Model(s): PFXSP5400WAD, PFXSP5400WAD (c), PFXSP5500WAD (c), PFXSP5600WAD (c)

**Class I, Division 2, Group A, B, C and D, Rear Module, Model(s):** GP-4000M, PFXGM4B01D

**Class I, Division 2, Group A, B, C and D, Rear Module, "Series Magelis", Model(s):** HMI, followed by -S5T, -SAC or -SBC, may be followed by a three-alphanumeric digit number

**Class I, Division 2, Group A, B, C and D, Rear Small Controller Universal, Model(s):** 4230020-09 through -12

**Class I, Division 2, Group A, B, C and D, replacement hard disks, Model(s):** HMIYADDVIRGB11

**Class I, Division 2, Group A, B, C and D, Small Controller rear model, Model(s):** PFXLM4B01DAC, PFXLM4B01DAK, PFXLM4B01DDC, PFXLM4B01DDK

**Class I, Division 2, Group A, B, C and D, Small Controller Universal, Model(s):** 4230020-01 through -08, PFXLM4201TADAC, PFXLM4201TADAK, PFXLM4201TADDC, PFXLM4201TADDK, PFXLM4301TADAC, PFXLM4301TADAK, PFXLM4301TADDC, PFXLM4301TADDK

**Class I, Division 2, Group A, B, C and D, Small Terminal, Model(s):** PFXGM4201TAD, PFXGM4301TAD

**Class I, Division 2, Group A, B, C and D, Small Terminal, "Series Magelis", Model(s):** HMI-STU followed by -655 or -855, may be followed by three-alphanumeric digits, or type LV434128 and Small Controller Universal HMI-SCU may be followed by -6A5, -8A5, -6B5, and -8B5, may be followed by three alphanumeric digits

**Class I, Division 2, Group A, B, C and D, solid state disks, Model(s):** HMIYSDD003211 (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, solid state disks, Model(s):** HMIYSDDxxxx11 (c) (&) - Where e= C, H, or F, f = A, D or B, g = 7, P or E, h = 0, F or L. (a) – Where x = P, W, T or V, Models followed by 9 letters or numbers. (b) – Where x = letters or numbers, y = W or V. (c) – Where x = Numbers indicating memory size (%) - Followed by 9 letters or numbers. (^) - Where x= C, H, or F,,y = E, P or 7, z = L, F, or 0. (#) - Followed by 9 letters or numbers. (@) - Followed by 4 letters or numbers.

**Class I, Division 2, Group A, B, C and D, Touch Panel Computer with Display, Model(s):** HMIBMOxxxxxxxxxxxxx Where "x" may be any alphanumeric character, "-" or blank for marketing purpose only, and no impact safety related constructions and critical components.

**Class I, Division 2, Group A, B, C and D, Touch Panel Computer with Display, Model(s):** HMIBMPxxxxxxxxxxxxx Where "x" may be any alphanumeric character, "-" or blank for marketing purpose only, and no impact safety related constructions and critical components.

**Class I, Division 2, Group A, B, C and D, Touch Panel Computer with Display, Model(s):** HMIBMUxxxxxxxxxxxxx Where "x" may be any alphanumeric character, "-" or blank for marketing purpose only, and no impact safety related constructions and critical components.

**Class I, Division 2, Group A, B, C and D, Touch Panel Computer with Display, Model(s):** HMIPCL2axbxxxxxxx The "a" can be B, 6, D, 7 or J The "b" can be A or D The "x" can be any alphanumeric character, "-" or blank.

**Class I, Division 2, Group A, B, C and D, Touch Panel Computer with Display, Model(s):** HMIPCC2axbxxxxxxx The "a" can be B, 6, D, 7 or J The "b" can be A or D The "x" can be any alphanumeric character, "-" or blank.

**Class I, Division 2, Group A, B, C and D, Touch Panel Computer with Display, Model(s):** HMIPCCU2axbxxxxxxx The "a" can be B, 6, D, 7 or J The "b" can be A or D The "x" can be any alphanumeric character, "-" or blank.

**Class I, Division 2, Group A, B, C and D, Touch Panel Computer with Display, Model(s):** PFXPL2axbxxxxxxx The "a" can be B, 6, D, 7 or J The "b" can be A or D The "x" can be any alphanumeric character, "-" or blank.

**Class I, Division 2, Group A, B, C and D, Touch Panel Computer with Display, Model(s):** PFXPP2axbxxxxxxx The "a" can be B, 6, D, 7 or J The "b" can be A or D The "x" can be any alphanumeric character, "-" or blank.

**Class I, Division 2, Group A, B, C and D, Touch Panel Computer with Display, Model(s):** PFXPU2axbxxxxxxx The "a" can be B, 6, D, 7 or J The "b" can be A or D The "x" can be any alphanumeric character, "-" or blank.

**Class I, Division 2, Group A, B, C and D, Touch Panel Computer with Display, Model(s):** TM901BMPxxxxxxxxxxxx The "a" can be B, 6, D, 7 or J The "b" can be A or D The "x" can be any alphanumeric character, "-" or blank.

**Class I, Division 2, Group A, B, C and D, Video mix units, Model(s): 3610001, 3710008-01, 3710013-01**

# - May be followed by any letter or number.

# - Any letter(s) and/or number(s) or blank.

(a) - Where \* may be any letter or number, # may be any one to three alphanumeric digits.

(a)

(b) - Where x = any letters or number.

(b)

(c) - May be followed by any one to three letter(s) and/or number(s).

(c)

(d) - Followed by 9 letters or numbers.

(d)

(e) - Followed by 9 letters or numbers, where x is any letters or number.

(e)

\* - May be followed by any letter or number.

\*

Last Updated on 2025-03-13

---

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL Solutions' Follow - Up Service. Only those products bearing the UL Mark should be considered to be Certified and covered under UL Solutions' Follow - Up Service. Always look for the Mark on the product.

UL Solutions permits the reproduction of the material contained in Product iQ subject to the following conditions: 1. The Guide Information, Assemblies, Constructions, Designs, Systems, and/or Certifications (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from Product iQ with permission from UL Solutions" must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "©2025 UL LLC."