1/12/2018 **Product Details** 

> **Product** Number:

22060

Order FO30/835/XP/SS/ECO3 Abbreviation:

General

30W, 48" MOL, T8 OCTRON SuperSaver fluorescent lamp, 3500K color Description: temperature, rare earth phosphor, 85 CRI, suitable for use on rapid or instant

ballasts or other T8 ballasts with minimum starting voltage of 550V,

ECOLOGIC®3

\* Full Case Required

## **Product Information**

Abbrev. With Packaging Info. FO30835XPSSECO3 30/CS 1/SKU

47.780 Actual Length (in) Actual Length (mm) 1213.61 40000 Average Rated Life (hr)

SYLVANIA

Base Medium Bipin

Bulb T8 Color Rendering Index (CRI) 85 3500 Color Temperature/CCT (K) 1.098 Diameter (in) 27.90 Diameter (mm)

Family Brand Name OCTRON® 800 XP® SS, ECOLOGIC®3

ANSI C78.81 - 2001 **Industry Standards** 

Initial Lumens at 25C 2850 Mean Lumens at 25C 2710 Nominal Length (in) 48.000 Nominal Length (mm) 1219.20 Nominal Wattage (W) 30.00 Life at 3 hrs./start on IS ballasts 24000 Life at 12 hrs./start on IS ballasts 40000 Life at 3 hrs./start on PRS ballasts 40000 Life at 12 hrs./start on PRS ballasts 42000



## **Footnotes**

- Approximate initial lumens after 100 hours operation.
- The life ratings of fluorescent lamps are based on 3 hr. operating cycles under specified conditions and with ballast meeting ANSI specifications. If operating cycle is increased, there will be a corresponding increase in the average hours life.
- Minimum starting temperature is a function of the ballast; consult the ballast manufacturer.
- OCTRON lamps should be operated only with magnetic rapid start ballasts designed to operate 265 mA, T-8 lamps or high frequency (electronic) ballasts that are either instant start, or rapid start, or programmed rapid start specifically designed to operate T8 lamps. OCTRON lamps may be operated on instant start or programmed rapid start ballasts with ballast factors ranging from a minimum of 0.71 to a maximum of

1/12/2018 Product Details

1.20 at the nominal ballast input voltage (see ballast specs for details). When OCTRON lamps are operated in the instant start mode, the two contacts (bi-pin lamps) of each rapid start lampholder/socket should be connected to each other or use "shunted" circle I lampholders/sockets for instant start bi-pin lamps. Always disconnect power before servicing installations and wire per the ballast schematics and National Electric

- SYLVANIA ECOLOGIC fluorescent lamps are designed to pass the Federal Toxic Characteristic Leaching Procedure (TCLP) criteria for
  classification as non-hazardous waste in most states. TCLP test results are available upon request. Lamp disposal regulations may vary, check
  your local & state regulations. For more information, please visit www.lamprecycle.org
- Mean lumens are measured at 40% of average rated lamp life.
- The distance between any parts of the lamp and any conductive surface of the luminaire should not be less than 3 mm (applies to all high frequency ballasted systems).
- The lamp should not be in contact with any surface of the luminaire (applies to either high frequency or 60Hz ballasted systems).
- SUPERSAVER (SS) lamps are recommended to be used on F32T8 Instant or Programmed Rapid Start ballasts with minimum open circuit voltage of 550V RMS at the lamp. Not recommended to be used: (1) in remotely ballasted fixtures with lamp open circuit voltages below 550V, (2) with Rapid Start ballasts unless the lamp open circuit voltage is greater than 570V, (3) in air handling fixtures, (4) on low power factor ballasts or (5) inverter operated emergency lighting systems unless the equipment is specifically listed for particular lamps. Any of the above situations could result in lamp starting and stabilization problems, or system compatibility issues. If an operating 28W, 21W or 15W SUPERSAVER lamp is exposed to drafts or the ambient temperature falls below 60°F (70°F for 25W), striation (a rhythmic pulsing pattern of light running down the tube) and/or reduction in lamp brightness may occur. While visually disconcerting, neither behavior is damaging to the lamp and removing the cause (draft or temperature) will return the lamp to normal operation.